





REZISTENTA LA APA

Rezistenta la apa		Tipul de utilizare in apa			
Marcajul pe spatele carcasei	Adancimea in metri				
		Spalarea pe maini	Dus/ Baie	Inot/Snorkeling	Sufundari
-	-	nu	nu	nu	nu
-	-	da	nu	nu	nu
3 ATM	30	da	nu	nu	nu
5 ATM	50	da	da	nu	nu
10 ATM	100	da	da	da	nu
20 ATM	200	da	da	da	da
30 ATM	300	da	da	da	da
50 ATM	500	da	da	da	da

Inainte de folosirea in apa verifica rezistenta la apa a ceasului tau, marcata pe spatele carcasei.

In cazul utilizarii frecvente in apa se recomanda schimbarea garniturii carcasei si garniturii remontoarului de catre un ceasornicar specializat, o data la 2 ani de zile.

Pentru a creste rezistenta la apa, nu este recomandata expunerea la apa fierbinte.

Dupa fiecare utilizare a ceasului in apa sarata, clateste abundent cu apa dulce si sterge apoi cu un material moale.